



IGN ON = red circuit is powered, ERS energized
 CRANKING = blue circuit powered, Lamp Test earthed, Fuel Pump Relay closed,
 12 V from brown circuit (battery direct) AND blue circuit
 RUN = Pump supply by blue circuit (ERS) only
 Dotted red + black : Forced Pump Relais Closure by alternate, supply direct from BAT

